

## [034Motorsport Turbo Inlet, MQB I4](#)



034Motorsport's Turbo Inlet is the new standard in performance. This turbo inlet was engineered with performance in mind. Manufactured from powder coated aluminum, for strength, light weight, and long lasting reliability.

## Installation Spiciness Rating



(Mild)

Installation of your 034Motorsport Turbo Inlet is a straightforward process that will take approximately 30 minutes to complete.

### Supplied Parts:

- 034Motorsport Turbo Inlet
- M8 socket head cap screw

### Tools Needed:

- T25 Torx
- T30 Torx
- Phillips head screwdriver
- 6mm Allen wrench
- Two hands, and most of your fingers

## About This Guide

This Install Guide documents the installation process on a 2015 Audi S3, a 2015 and a 2018 VW Golf GTI. There may be minor differences with other vehicles, depending on specific vehicle, market, options, etc.

## Getting Started

- Ensure you have all parts and tools required for installation by reading the complete Install Guide.


## Step 1

### Open Hood



## Step 2

Using a Phillips head screwdriver, or appropriate socket, loosen the hose clamp holding the intake to the turbo inlet.



## Step 3

Remove the breather hose from the left side of the airbox.



## Step 4

Using a T25 Torx, remove the upper airbox screws.



## Step 5

Remove the upper airbox.



## Step 6

Using a T30 Torx, remove the screw holding the stock turbo inlet.




## Step 7

Take a hold of the turbo inlet, and turn clockwise to disengage from turbo.



## Step 8

Disconnect breather hose from inlet. It will be either a pinch type connector, or a friction snap-on. The pinch connector is easy to remove, while the friction snap-on will require effort; pulling while simultaneously rocking the connector is usually the best way to remove.



## Step 9

Apply a small amount of Blue Loctite to the supplied M8 socket head cap screw.



## Step 10

Install the 034Motorsport Turbo Inlet. Connect the breather hose (it will click in).

Torque the M8 socket head cap screw to 9NM (6.5 ft-lbs).



## Step 11

Reinstall the upper airbox.

Torque the T25 Torx screws to 4NM.



## Step 12

Connect airbox tube to the turbo inlet. Tighten hose clamp to 5NM.



## Step 13

Reconnect the breather hose on left side of airbox (disconnected in Step 4)





## Step 14

Reinstall engine cover.



## Step 15

Close the hood, and enjoy the performance of the 034Motorsport Turbo Inlet!