

MILLTEK

SYSTEM NO.	SSXLR160		
VEHICLES	YEARS		
LANDROVER DEFENDER V8 P425 – P525	2021 Onward		
NOTES	Remote Operated Valve Control. Button 1 – Valves Open Button 2 – OE Mode Button 3 – Valves closed		

1. Firstly, ensure the vehicle is turned off, open the boot and place the key at least 5M away from the vehicle, wait 15 minutes with the boot open so that the vehicle is fully at rest and no lights are on, do not touch the vehicle in this time.
2. Remove the boot floor so that you can locate the grommet required to run the cable to the outside of the vehicle. Remove the rubber grommet completely to make install easier, it will be placed back again later on.



3. Pull the plug connectors down through this hole, ensuring they cannot be caught in any moving parts or damaged by heat.
4. Lay the cables to the exhaust valves, the wiring will plug between the original valve wiring and the exhaust motor.
5. Push any excess wiring back up into the vehicle and then tie the cables and module neatly up, ensure that the module is secured somewhere safe.
6. Replace the grommet, you may need to cut it slightly to make it fit, if so, you will then need to seal with silicone sealant.