

SWAY BAR END LINKS, MOTORSPORT, REAR, ADJUSTABLE, 8P & 8J AUDI TT/A3, MKV & MKVI VOLKSWAGEN JETTA GTI R32 RABBIT

Sway Bar End Links, Motorsport, Rear, Adjustable, 8P & 8J Audi TT/A3, MkV & MkVI Volkswagen Jetta GTI R32 Rabbit

034Motorsport's Billet Adjustable Rear Sway Bar End Links allow for uncompromised transfer of suspension movement to the sway bar, and are adjustable in length.



About This Guide

This Assembly Guide documents the process of the proper configuration prior to installation with the 034Motorsport parts that you have just purchased! Pictures and part numbers may vary, but the process remains the same.

Getting Started

 Confirm you have received all of the parts included with your purchase, if there are missing components, please contact <u>customerservice@034motorsport.com</u>

Collect the necessary tools required for installation by reading the complete Assembly Guide.

*Some photos may omit the anti-seize packet, but it's there!





SWAY BAR END LINKS, MOTORSPORT, REAR, ADJUSTABLE, 8P & 8J AUDI TT/A3, MKV & MKVI VOLKSWAGEN JETTA GTI R32 RABBIT

Supplied Parts:

- (2x) billet sway bar end links with spherical bearings and circlips installed
- (4x) end link spacers
- (2x) spherical heim joints with jam nuts
- (2x) M10 x 55mm bolts
- (2x) M10 x 60mm bolts
- (4x) nylon locking nuts
- (2x) dust boots
- (1x) anti-seize packets

Tools Needed:

• (2x) capable hands

* We ship the dust boots uninstalled; once you have the fitment set, install the dust boots before final installation (optional).





SWAY BAR END LINKS, MOTORSPORT, REAR, ADJUSTABLE, 8P & 8J AUDI TT/A3, MKV & MKVI VOLKSWAGEN JETTA GTI R32 RABBIT

Steps

• Open hardware packages



Apply half packet of anti-seize to each spherical heim joint





SWAY BAR END LINKS, MOTORSPORT, REAR, ADJUSTABLE, 8P & 8J AUDI TT/A3, MKV & MKVI VOLKSWAGEN JETTA GTI R32 RABBIT

• Run the jam nut down the shaft to disperse the anti-seize along the entire threaded portion



 Install the heim joint into the billet end links, leaving about 2-3 threads exposed



*For lowered vehicles, always check all clearances over the full articulation of the suspension in order to identify possible interference